



ELMI

USER MANUAL

Water thermostat TW-2





Content

Dear user.....	3	Troubleshootin.....	5
General information.....	3	Safety features.....	5
Technical specifications.....	3	Disinfection and cleaning.....	5
Delivery package.....	3	Transportation and storage.....	5
Preparation to work.....	4	Warranty statements.....	6
Control description.....	4	Certificate of approval.....	6
Operation.....	5		

Water thermostat TW-2

ELMI

Dear user!

Water thermostat TW-2 is simple and reliable device. We ask you to consider technical requirement for exploitation to provide the use of the equipment without problems for a long period of time.

Water bath TW-2 is composed of the stainless steel water tank with the transparent lid and control block. The control block has LED displays and control buttons on top. Control block should be placed on the water tank and fixed by screw. On the bottom side of the control block heater and water

pump are situated. On the back side of the control block two pipes are situated for connecting the water thermostat to an outer contour and maintaining the temperature in the outer contour same as in the stainless steel water tank.

The device is designed to maintain the desired temperature regime with high level of accuracy. This device is fully controlled by the microprocessor system with memory independent from the source of energy.

General information

Magnetic Stirrer MS-01 is designed for mixing any kind of liquid media with magnetic bars inside the various types of laboratory flasks.

Machine is perfectly suitable in microbiology, chemistry, medicine etc.

Technical specifications

Temperature range in the bath, °C	from room temp. to +100
Accuracy of temperature maintenance in the bath, °C	+0,1
Environmental temperature, °C	from +10 to +40
Maximal time of set temperature achievement, min	50
Minimal water capacity in tank, L	6
Maximal water capacity in tank, L	8,5
Relative moisture of atmosphere (at the temperature of 20°C)	not more than 80%
Temperature stabilization above the environmental, °C	not less than 3
Water pump productivity for external heating pipes (variable) L/min	2-5
Voltage and frequency:	220 V, 50 Hz
Power consumption, kW	not more than 1,5
Size of the device (length x width x height) mm:	320 x 265 x 260
Weight (without fluid), kg	4,9

Delivery package

Item	Quantity
Control block	1
Stainless steel tank	1
Lid	1
User's manual	1
Packaging	1

Water thermostat TW-2

Preparation to work

1. Unpack the device.
2. Inspect all parts of the water bath for damage.
3. Put device on horizontal solid surface.
4. Connect the control block to the tank by fixing the screw in the back.
5. Fill the reservoir with 6 liters minimum of distilled water (do not use any electrolyte solvents).
6. Plug the cord into the outlet with voltage of 220 V and frequency of 50 Hz.

Control description




Water thermostat consists of a stainless steel tank and control block. Water tank is covered with trans-

parent lid. The control block displays and buttons have the following functions:



Water thermostat TW-2 **ELMI**


Operation

Turn on the device by pressing button  and set the desired temperature by   buttons. The device will start heating up immediately. The set temperature is displayed for the first 10 seconds after adjusting, afterwards the actual temperature is displayed.

To check the set temperature press one time on the button for adjusting the temperature. The dot on the temperature display separating the integers

from tenths of a set temperature value indicates what temperature is displayed:

- if the dot is blinking - set temperature is displayed,
- if the dot is glowing - actual temperature is displayed.

Set the desired water circulation level in tank or water flow speed in external heating pipes from 2-5 liters per minute by pressing the  button.

Troubleshooting

Error code	Cause	Solution
No display.	No main power connection. Power failure.	Plug in power cord. Check the voltage in network.
ERR-1	Failure of temperature sensor.	Replace the temperature sensor.
ERR-2	Failure of water pump.	Replace the water pump.
LEVEL	Insufficient water level.	Add water to the tank.

General information

Safety features

Service personnel are prohibited to:

- Plug the device in to a power outlet with configuration that differs from the power adapters configuration.

- Use the device with damaged power cord, water tank, control block.
- Move the device during work.

ATTENTION! *Studied Samples may contain pathological material, including pathogens of serious diseases.*

Disinfection and cleaning

Before you start disinfection or cleaning make sure the power cord is unplugged. It is recommended to perform cleaning with water and universal washing

liquids. Afterwards the machine should be carefully dried. Do not let the water get inside the control block.

Transportation and storage

To insure safety during the transportation, transported equipment should be packed in the original manufacturers packaging or similar packaging substitute.

Equipment can be transported by any kind of closed transport make sure that equipment is tightly fixed and transportation runs accordingly to regulations

applied to this way of transport. Equipment should be stored in original manufacturers packaging in dry room with humidity not more than 80% and temperature range from +10°C up to +40°C. It is not recommended to store the equipment more than 36 month.

Water thermostat TW-2

Warranty statements

- Warranty applies to 24 month period from the date of purchasing.
- Malfunctions arisen by the fault of manufacturer during warranty period, are removed free of charge.
- Warranty is not valid in the following cases:
 - If the serial number label of the manufacturer is damaged.
 - If damages appears as a result of the incorrect operation, transportation or storage. These documents are necessary if applying for warranty repair:
 - User manual with serial number of the machine.
 - Officially signed report, describing the reasons and conditions of equipment malfunction. Warranty repair could be performed only if the equipment is delivered in the original manufacturers packaging or equally safe packaging. Therefore please save the packaging after unpacking the device.
- If the above warranty requirements are disturbed, repair charges are applied to the consumer.
- For all further questions concerning exploitation and maintenance please contact manufacturer or product vendor.

Certificate of approval

Water thermostat TW-2 ____

N^o _____

has been inspected for the technical conditions and meets all regulations necessary for this class of device.

Quality control person _____
(name) (signature)

Date of manufacture _____

Place for stamp.

Certificate of sale Organization _____

Phone _____

Address 1 line _____

Vendor _____ (name) (signature).

Address 2 line _____

Date of sale _____

North America

Phone:

(805) 375-0060

3483 Old Conejo Rd., STE 206

Newbury Park, CA 91320

info@elminorthamerica.com

elminorthamerica.com

Europe

Phone:

(371) 6755-8743

21-133 Aizkraukles Str., Riga LV-1006

Fax: (+371) 6755 1934

E-mail: info@elmi-tech.com

www.elmi-tech.com