

QIMAGING QUICK INSTALLATION GUIDE



Install the Camera-Interface Software

1. Install the IEEE-1394 card in your computer (refer to the video <http://www.qimaging.com/qitube/?v=installing-pci-card>). **Note:** The camera is powered through the firewire cable. Therefore, you will need to connect power to the firewire card from the computer power supply, or use a powered firewire cable.
2. Power on the computer and insert the QCapture Suite disc into your CD or USB drive.
3. Install camera drivers and Q-Capture Suite software by choosing one of these options:
For Windows 32 bit run:
"D:\Installers\Windows\32bit\QCamx32_Setup XXXX)"
For Windows 64 bit run:
"D:\Installers\Windows\64bit\QCamx64_Setup XXXX)"
For Mac OS X:
"D:\installers\Mac\Qcapture Suite PLUS.pkg"
(**Note:** The letter for your CD drive is assumed to be D. If D is not your CD drive, use the appropriate letter.)
4. Follow the installation instructions on screen.
5. Restart your computer and connect the camera to the PC.
6. If you purchased the QCapture Pro software, please follow the installation instructions on the QCapture Pro USB in the Document folder.

MicroPublisher™ 3.3 & 5.0



1. Plug one end of the cable into one of the camera's Firewire sockets (either socket is fine). Plug the other end of the cable into a Firewire port of your computer.



WARNING: Your camera will be damaged if the IEEE 1394 cable is not plugged into **BOTH** the computer **AND** the camera correctly. The cable connectors only fit one way and should slide easily into ports as shown below. Plugging the cable in improperly will void your warranty and require the camera to be returned to QImaging for repair.



More detailed installation instructions can be found in the camera instruction manual on the QImaging CD.

Contact QImaging Customer Service for additional information: 1-800-874-9789 or www.qimaging.com



www.qimaging.com

©2013 QImaging. All rights reserved.

03-0024 Rev A0